



Resin Claw Kit Installation

The following steps will show you how to install your Resin Claws / LED claws. If you have any other questions please email us at support@roofur.com and we will get with you shortly. Thank you!



Figure 1.



Figure 2.



Figure 3.

For ease, turn paw inside out.



Figure 4.

Then flip the paw so it's facing palm down.



Figure 5.

To make the opening for the claw, make a small incision right above the seam.



Figure 6.

Make the opening between 1/4" to 3/8" .



Figure 7.

Continue cutting all the rest of the fingertips.



Figure 8.

Turn paw right side out now and you should notice the small incisions.



Figure 9.

Now we will push the claws and harness inside the paw, working each claw to each finger.



Figure 10.

Work the claw through the opening.



Figure 11.

The claw should fit a little tight; this is alright because we want the claw to stay pretty stationary.



Figure 12.

Swivel the claws when finished for appropriate look.



Figure 13.

You have completed the installation!



Figure 14.

Plug in and glow! ^.^